



Fog Lights With High Beams

by Flopster843

19 July 2009

Summary:

By default all vehicles disable the fog lights when your high beams are turned on. This is not a hardware issue, it's a software issue. Meaning, it can be changed in the computer. Having the fog lights on with your high beams drastically improves visibility at night and eliminates a large dark spot directly in front of your truck.

Enabling:

To enable this function your dealership must reprogram the truck's computer using the Starscan. The dealership I went to charged me a total of \$31.90 to enable the fog lights and the high idle in the computer. (I highly suggest doing both at the same time, definitely worth the money.) You need to "export" the computer to make it think it's in a different country. Basically, you have to make your truck think that it's Mexican. The Starscan procedures are as follows:

Starscan Main Menu > ECU view > FCM/CGW > Misc. Functions > Enable Front Fog Lamp Output > Start > Next > Disable > Next > Cancel > Start > Next > Enable > Next > Export > Next > Finish

That's all there is to it. Enjoy using your fog lights with your high beams.

